


TVAR: IM 1081 **B3**

# ROZMERY



TYP	A	AA	AB	AC	AG	B	BB	C	CA	H	HA	HD	HF
4AP 56-.s	90	25	110	104	72	71	100	36	76	56	7	144	70
4AP 56-.													
4AP 63-.s	100	26	116	118	72	80	96	40	66	63	7	158	76
4AP 63-.													
4AP 71-.s	112	32	132	132	72	90	106	45	71	71	8	173	83
4AP 71-.													
4AP 80-.s	125	36	150	154	87	100	126	50	83	80	9	198	96
4AP 80-.													
4AP 90S-.	140	39	167	172	87	100	127	56	91	90	10	214	102
4AP 90L-.						125	145		86				

[illegible]