


TVAR: IM 3081 **B5** ➤

# ROZMERY



TYP	M	N	P	S	T	W	D-DA	E-EA	F-FA	G-GB	GO-GF
4AP 56-.s	100	80	120	7	3	P13.5	9	20	3	7,2	3
4AP 56-.											
4AP 63-.s	115	95	140	10	3	P13.5	11	23	4	8.5	4
4AP 63-.											
4AP 71-.s	130	110	160	10	3.5	P13.5	14	30	5	11	5
4AP 71-.											
4AP 80-.s	165	130	200	12	3.5	P16	19	40	6	15.5	6
4AP 80-.											
4AP 90S-.	165	130	200	12	3.5	P16	24	50	8	20	7
4AP 90L-.											